

## Leather Maintenance

Leather is a substance that must be looked after with care. All leather products need regular maintenance to ensure their lasting appeal and durability. Leather is similar to human skin and requires cleaning and nourishing. Regular contact with moisture (rain, sweat and urine etc.) can cause rigidity. Our leather protection coating contains organic palm oil, lipidure, shark liver oil and collagen. This ensures the leather is left soft, shiny and smooth but not oily. This also protects leather from dirt and watermarks. The Leather Maintenance Service also includes an interior detailed steam clean.

## Interior Care

Many vehicle owners drive their vehicles with closed windows which hold crumbs, hair and dirt inside creating a breeding ground for bacteria. Our Nano Titanium Interior Coating deodorizes and sanitizes car interior and upholstery. It also offers virus protection for the interior surfaces and helps remove the scent of cigarettes. We suggest this service be undertaken every 6 months.

